



SAMSUNG QUICK REFERENCE GUIDE

For Changing Station Class of Service

GETTING STARTED

Changing Station Class of Service

MMC 301: Assign Station COS

DESCRIPTION:

Used to assign day and night class of service to each keyset. There are 30 different classes of service that are defined in MMC 701 - Assign COS Contents. Classes of service are numbered 01-30.

PROGRAM KEYS

UP & DOWN	Used to scroll through options
KEYPAD	Used to enter selections
SOFT KEYS	Move cursor left and right
SPK	Used to store data and advance to next MMC
HOLD	Used to clear previous entry
ANS/RLS	Used to select ALL

ACTION

DISPLAY

- | | |
|---|---|
| <p>1. Press TRSF 301
Display shows first station</p> | <p>[201] STN COS
DAY : 01 NIGHT : 01</p> |
| <p>2. Dial station number (eg., 205)
OR
Use UP and DOWN to scroll through stations and press RIGHT soft key to advance to step
OR
Use UP and DOWN to scroll through stations and press LEFT soft key to advance to step
OR
Press ANS/RLS to select all stations</p> | <p>[205] STN COS
DAY : 01 NIGHT : 01</p> |
| <p>3. Enter day class of service (eg., 05)
OR
Use UP and DOWN to scroll through classes of service and press RIGHT soft key to advance to step 4
OR
Use UP and DOWN to scroll through classes of service and press LEFT soft key to return to step 2</p> | <p>[205] STN COS
DAY : 05 NIGHT : 01</p> |
| <p>4. Enter night class of service (eg., 05)
OR
Use UP and DOWN to scroll through classes of service and press RIGHT soft key to return to step 2
OR
Use UP and DOWN to scroll through classes of service and press Left soft key to return to step 3</p> | <p>[205] STN COS
DAY : 05 NIGHT : 05</p> |
| <p>5. Press TRSF to save and exit</p> | |