


GETTING STARTED

Programming Headset Mode

Switching Headset/Handset Mode

You can switch between handset mode and headset mode if you have a headset connected to your phone. In headset mode, you answer or end a call by pressing the [Send] or [End] button.

1. Press the [Transfer] button.
2. Press [1][1][0].
3. To use the handset, press [0][2][0]
To use the headset, press [0][2][1]
4. Save the selected entry by pressing the [Transfer] button.



If your phone has a headset mode on/off button, press this button. The button's LED will light when headset mode is set. Press again to return to handset mode. The LED goes off.